



**Voicemail  
Quick Reference Card**

Default Voicemail Menu

Residential Feature Set  
T6000 Release 6.0

© 2006 EasyOn. All rights reserved.

QR-60-1004-010507

**Accessing Your Voicemail**

**From Your Own Phone**

Press the Messages button or dial \*09  
Enter your voicemail password  
If you have new messages, the messages will be identified and played.  
After hearing any new messages, you will be presented with the Voicemail Main Menu. The Main Menu options are listed below.

**From Another Phone**

From another phone, dial the voicemail access number specified by your Service Provider.  
When prompted, enter your extension number  
When prompted, enter your voicemail password + #  
If you have new messages, the messages will be identified and played. After hearing any new messages, you will be presented with the Voicemail Main Menu. The Main Menu options are listed below.

**From the Web Portal**

If you have a Web Portal account, you can retrieve messages and manage your voicemail account using the Web Portal. For information about using your Web Portal, refer to your Web Portal documentation or the online help system available once you've logged into your Web Portal account.

**From an Email Client**

Your service provider may allow you to access your voicemail account using your standards-based (i.e., IMAP or POP) email client. Contact your service provider to see if this service is available and to obtain the necessary information to configure your email client.

**Voicemail Main Menu**

KEY	FEATURE
1	Play Inbox Messages
2	Play Saved Messages
3	Change Password
4	Play Greetings
5	Record Greetings
7	Compose a New Message
8	Manage Custom Operator Number
*	Exit to Voicemail System

**Message Playback Options**

While listening to your voicemail messages, the following options are available.

ACTION	BEFORE MESSAGE	DURING MESSAGE	AFTER MESSAGE
Skip Envelope	NA	#	NA
Skip Message	8	NA	8
Reply to Message	2	2	2
Call Originator	3	3	3
Delete	4	4	4
Save	5	5	5
Forward Message	6	6	6
Replay Message	NA	77	7
Rewind 5 Seconds	NA	7	NA
Pause/Resume Playback	NA	8	NA
Skip Ahead 5 Seconds	NA	9	NA
Skip to the End	NA	99	NA
Skip to Previous Menu	*	*	*

**Replying to a Message**

While listening to a message, press 2 to reply  
After the tone, record a message and press #  
Select an action

To Send the message, press 1. The message will be sent and you will be returned to the previous menu.

To Change the message, press 2. The message will be deleted and you will be prompted to record the message again.

To Review the message, press 3. The message will be played back and you will be prompted to select another action.

To Mark the message Urgent and Send, press 9. The message will be marked urgent and sent.

You will be disconnected from the voicemail system. When retrieving messages, urgent messages will be played first. If configured by the recipient, the recipient may be paged when they receive an urgent message.

Press \* to cancel

### Dialing the Originator

While listening to a message, you can call the person back by pressing 3.

This capability will not work if the voicemail system was not able to record the Caller ID information when the original voicemail was received or if your phone is configured with call restrictions which prevent you from calling the originator's number.

### Forwarding a Message

While listening to messages, you can forward a message to another recipient. To forward the current message, press 6.

Enter a telephone number + #. Repeat this step until you've entered all the desired destinations.

Press # when finished entering destinations

You will be prompted to record an introduction

After the tone, record your introductory message and press # when finished.

Select an action

To Forward the message, press 1. The message will be sent.

To Change the introductory message, press 2.

The message will be deleted and you will be prompted to record the message again.

To Review the introductory message, press 3.

The message will be played back and you will be prompted to select another action.

To Mark the message Urgent and Send, press 9.

When retrieving messages, urgent messages will be played first. If configured by the recipient, the recipient may be paged when they receive an urgent message.

Press \* to Cancel.

### Composing a New Message

Access your voice mailbox

If you have new messages, the messages will be identified and played. To skip to the Main Menu, press \*.

From the Main Menu, press 7 to compose a new message

Enter a telephone number + #. Repeat this step until you've entered all the desired destinations.

Press # when finished entering destinations

After the tone, record your message. Press the # key when finished.

Select an action

To Send the message, press 1. The message will be sent and you will be disconnected from the voicemail system.

To Change the message, press 2. The message will be deleted and you will be prompted to record the message again.

To Review the message, press 3. The message will be played back and you will be prompted to select another action.

To set Message Options, press 4.

To mark the message Urgent, press 1.

To mark the message Private, press 2.

To request a Return Receipt, press 3.

To clear all these options, press 9.

To return to the previous menu, press \*.

### Changing Your Voicemail Password

Access your voice mailbox

If you have new messages, the messages will be identified and played. To skip to the Main Menu, press \*.

From the Main Menu, press 3 to change your password

Enter your new password + #

Enter your new password again + # to confirm

### Recording Your Personal Greetings

Access your voice mailbox

If you have new messages, the messages will be identified and played. To skip to the Main Menu, press \*.

From the Main Menu, press 5 to record your greetings

Select the greeting you'd like to record:

To record a No Answer greeting, press 1

To record a Do Not Disturb greeting, press 2

To record a Busy greeting, press 3

To record your Name, press 4

To return to the main menu, press \*

After the tone, record your greeting. Press # when finished.

If you don't record a personal greeting, a generic greeting will be played.

### Hearing Your Personal Greetings

Access your voice mailbox

If you have new messages, the messages will be identified and played. To skip to the Main Menu, press \*.

From the Main Menu, press 4 to hear your recorded greetings

Select the greeting you would like to hear:

To hear your No Answer greeting, press 1

To hear your Do Not Disturb greeting, press 2

To hear your Busy greeting, press 3

To hear your Name, press 4

To return to the main menu, press \*

### Operator Assistance Number

Callers can escape from your voice mailbox by pressing 0 while hearing your mailbox greeting. You can configure where callers are transferred when they escape from your voice mailbox. Your default Operator Assistance Number is usually your company's main telephone number.

#### To Configure Your Operator Assistance Number

Access your voice mailbox

If you have new messages, the messages will be identified and played. To skip to the Main Menu, press \*.

From the Main Menu, press 8 to manage your Custom Operator Assistance Number

The system will announce your current Operator Assistance Number

To configure your operator assistance number, press 1.

Enter your operator assistance number followed by #

The system will announce your new operator assistance number and return you to the Main Menu.

To Restore your Default Operator Assistance Number, press 2. The system will announce that you've been returned to the default custom operator number and return you to the Main Menu

To return to the Main Menu, press \*

### Email Forwarding

If desired, you can configure the voicemail system to automatically forward a copy of every voicemail message that you receive to a specified email address. Email Forwarding is configured via your Web Portal account.

### Pager Notifications

Pager Notifications are used to notify you when you receive voicemail messages. You can select whether or not to be notified and, if so, for which types of messages (i.e., All Messages or Urgent Messages Only).

You can choose to be notified in one of three different ways:

Numeric Pager - A numeric code will be sent to your pager.

Voice - The system will call you at a specified number and ask for your voicemail password. After entering your password, you can listen to your

messages. If the system doesn't reach you, it will try to reach you three times at five minute intervals.

Email - You'll receive an email that identifies the Date, Time, and ID of the caller.

Pager Notifications are configured using the Web Portal.

For more information about configuring Pager Notifications, see Web Portal User's Guide.